

NXC5500/2500

Version 4.21 Edition 1, 11/2015



Application Note

Copyright © 2015 ZyXEL Communications Corporation

Contents

Contents	0
Smart Client Steering	1
Smart Client Steering Introduction	1
Terminologies of Smart Client Steering	1
How Does It Work?	2
Configuration	
Dual-optimized Antenna Switch	6
Dual-optimized Antenna Switch Introduction	6
Terminologies of Dual-optimized Antenna Switch	7
How Does It Work?	7
Configuration	
ZyXEL One Network Utility Supports Managed AP	
ZyXEL One Network Introduction	
How Does It Work?	
Portal Redirection on Managed AP Application	
Portal Redirection on Managed AP Application Introduction	
How Does It Work?	
Application Scenario	
Conclusion:	

Smart Client Steering

Smart Client Steering Introduction

What is Smart Client Steering?

Due to the Bring Your Own Device (BYOD) trend, more and more access points (APs) are being deployed to meet the connectivity requirements of handheld devices. However, the 2.4 GHz frequency band which is commonly used by handheld devices is often congested. Gadgets running on the 2.4 GHz frequency typically experience interference from Bluetooth devices, electronics such as microwave ovens, and cordless phones, as well as co-channel interference from other APs, considering there are only three non-overlapping channels available for the IEEE 802.11 b/g/n wireless standards. The Band Select function enables devices with dual-band capability (2.4 GHz and 5 GHz) to move to a less congested AP that is operating on 5 GHz. Thus, the 5 GHz channel becomes an alternative choice for providing Wi-Fi service. The Band Select function provides a better wireless experience for users.

While more and more clients support the 5 GHz frequency, wireless resource optimization becomes more and more important. To avoid the legacy clients from occupying the wireless resource, ZyXEL provides some features to improve the wireless network.

- This technology helps:
 - Optimize wireless spectrum usage
 - Improve user experience

Terminologies of Smart Client Steering

Client Band Select

Band Select allows devices with dual-band capability (2.4 GHz and 5 GHz) to move to a less congested AP operating on 5 GHz. Thus, the 5 GHz channel utilization is further enhanced when providing Wi-Fi service.

Client Band Balancing

✤ Today there are more and more 5 GHz capable clients. This function helps to prevent situations such as 5 GHz radio overload and 2.4 GHz radio underload, thus provides a well-balanced spectrum utilization.

RSSI Threshold

RSSI is an indication of the power level being received by the access point. Thus, the higher the RSSI number, the stronger the signal. With the RSSI threshold settings, users can specify a signal strength level to prevent poor signal clients from affecting the wireless network.

How Does It Work?

- Features with band select and client signal thresholds
- Monitor the capabilities of each wireless client and direct the clients to the best radio on the best AP by using the band select and signal thresholds.



Smart Client Steering supports the Client Band Balancing feature which detects dual-radio clients and distributes clients across the 2.4 and 5 GHz band APs based on two independent configurable parameters - Stop Threshold & Balance Ratio.



Configuration

Band Select / Band Balance Web GUI Setting Path: Configuration > Object > AP Profile > SSID

Edit SSID Profile Test-5G ? X										
🛅 Create new Object 🗸										
Profile Name:	Test-5G									
SSID:	Test-5G									
Security Profile:	Amber	~								
MAC Filtering Profile:	disable	~								
Layer-2 Isolation Profile:	disable	~								
QoS:	WMM	•								
Rate Limiting (Per Station T	raffic Rate)									
Downlink: 0	mbps 💌 (0~160, 0 is un	limited)								
Uplink: 0	mbps 💌 (0~160, 0 is un	limited)								
Band Select:	standard	~								
Stop Threshold	15 Station (10~20)									
Balance Ratio	4:1 Y (5GHz : 2.4GHz)									
Forwarding Mode:	Local bridge	~								
VLAN ID:	1 (1	~4094)								
Hidden SSID										
📃 Block Intra BSS Traffic										
		OK Cancel								

♦ Stop Threshold:

Select this option and set the threshold number of the connected wireless clients with the Band Select feature disabled.

♦ Balance Ratio:

Select this option and set a ratio of the wireless clients using the 5 GHz band to the wireless clients using the 2.4 GHz band.

♦ Notice:

The ideal ratio is to make full use of the two radios. The current status depends on the client's wireless card behavior. For example, more and more dual-band capable clients has 5 GHz set as the default preference. This feature will impact the actual ratio that you set in the **Band Select-Balance Ratio** option.

RSSI Threshold

Web GUI Setting Path: Configuration > Object > AP Profile > Radio

Hide Advanced Settings Country Code: Switzerland Guard Interval: ● Short ● Long Image: Country Code: Short ● Long Image: Country Code: ● Short ● Coonception A-MPDU Limit: 50000 (100-65535) A-MPDU Subframe: 32 (2200-4096) RTS/CTS Threshold: 2347 (0-2347) Beacon Interval: 100 (40ms-1000ms) DTIM: 2 (1-255) Image: Construction Signal Threshold: -76 dBm (-2076) Disassociate Station Threshold: -105 dbm (-20105) Image: Allow Station Connection after Multiple Retries Station Retry Count: 6 (1 ~ 100) Multicast Settings 1 (1 ~ 100) 6 (1 ~ 100) Image: Color Contection after Multiple Retries 5.5 (11 ~ 0 6 9	😳 Edit Radio Profile default						? ×
Country Code: Switzerland Guard Interval:	Hide Advanced Settings						
Guard Interval:	Country Code:	Switzerland	~				•
✓ Enable A-MPDU Aggregation A-MPDU Limit: 0000 32 (2-64) ✓ Enable A-MSDU Aggregation A-MSDU Limit: 4096 (2290~4096) RTS/CTS Threshold: 2347 (0-2347) Beacon Interval: 100 (40ms-1000ms) DTM: 2 (2 (1~255) ✓ Enable Signal Threshold: -76 Station Signal Threshold: -105 Station Signal Threshold: -105 Ø Allow Station Connection after Multiple Retries Station Retry Count: Station Retry Count: 6 1 Ø Allow Station Connection after Multiple Retries Station Retry Count: 6 Ø Allow Station Connection after Multiple Retries 9 1 2 5.5 Ø Allow Station Connection after Multiple Retries 1 0 6 9 1 2 Ø 24 0 36 48 54	Guard Interval:	Short	Cong				
A-MPDU Limit: 50000 (100-65535) A-MPDU Subframe: 32 (2~64) ✓ Enable A-MSDU Aggregation A-MSDU Limit: 4096 (2290~4096) RTS/CTS Threshold: 2347 (0~2347) Beacon Interval: 100 (40ms~1000ms) DTIM: 2 (1~255) ✓ Enable Signal Threshold: -76 Station Signal Threshold: -76 dBm (-20 ~-76) Disassociate Station Threshold: -105 dbm (-20 ~-105) ✓ Allow Station Connection after Multiple Retries Station Retry Count: 6 (1 ~ 100) Multicast Settings Multicast to Unicast ♥ Fixed Multicast Rate Multicast Rate(Mbps): 0 1 2 5.5 11 6 9 12 18 0 24 36 48 54 54 0K Cancel	Enable A-MPDU Aggregation						
A-MPDU Subframe: 32 (2-64) Enable A-MSDU Aggregation A-MSDU Limit: 4096 (2290-4096) RTS/CTS Threshold: 2347 (0~2347) Beacon Interval: 100 (40ms~1000ms) DTIM: 2 (1~255) Enable Signal Threshold: .76 dBm (-20 ~-76) Disassociate Station Threshold: .105 dbm (-20 ~-105) Allow Station Connection after Multiple Retries .105 dbm (-20 ~-105) Allow Station Connection after Multiple Retries .10 .10 10 Multicast Settings Multicast to Unicast ● Fixed Multicast Rate Multicast Rate(Mbps): 0 1 0 2 0 5.5 0 11 6 9 12 18 0 24 36 48 54 54 0K Cancel	A-MPDU Limit:	50000	(100~65535)				
Image: Second	A-MPDU Subframe:	32	(2~64)				
A-MSDU Limit: 4096 (2290-4096) RTS/CTS Threshold: 2347 (0~2347) Beacon Interval: 100 (40ms~1000ms) DTIM: 2 (1~255) Image: Construction Signal Threshold: -76 dBm (-20 ~ -76) Disassociate Station Threshold: -105 dbm (-20 ~ -105) Image: Allow Station Connection after Multiple Retries Station Retry Count: 6 (1 ~ 100) Multicast Settings Transmission Mode: Image: Allow State Construction after Multicast to Unicast Image: Fixed Multicast Rate Multicast Rate(Mbps): 1 2 5.5 11 6 9 12 18 24 36 48 54 0K Cancel	👿 Enable A-MSDU Aggregation						
RTS/CTS Threshold: 2347 (0-2347) Beacon Interval: 100 (40ms~1000ms) DTIM: 2 (1-255) Image: Construction Signal Threshold 2 (1-255) Image: Construction Signal Threshold: -76 dBm (-20 ~ -76) Disassociate Station Threshold: -105 dbm (-20 ~ -105) Image: Construction after Multiple Retries Station Retry Count: 6 (1 ~ 100) Multicast Settings Multicast to Unicast Image: Fixed Multicast Rate Multicast Rate(Mbps): 1 2 5.5 11 6 9 12 18 24 36 48 54 54	A-MSDU Limit:	4096	(2290~4096)				
Beacon Interval: 100 (40ms~1000ms) DTIM: 2 (1~255) Image: Constraint of the shold 2 (1~257) Image: Constraint of the shold -76 dBm (-20 ~ -76) Disassociate Station Threshold: -105 dbm (-20 ~ -705) Image: Constraint of the shold: -105 dbm (-20 ~ -705) Image: Constraint of the shold: -105 dbm (-20 ~ -705) Image: Constraint of the shold: -105 dbm (-20 ~ -705) Image: Constraint of the shold: -105 dbm (-20 ~ -705) Image: Constraint of the shold: -105 dbm (-20 ~ -105) Image: Constraint of the shold: -105 dbm (-20 ~ -105) Image: Constraint of the shold: -105 dbm (-20 ~ -105) Image: Constraint of the shold: -105 dbm (-20 ~ -105) Image: Constraint of the shold: -105 -11 ~ 00) Image: Constraint of the shold: -100 -11 ~ 00 Image: Constraint of the shold: -11 ~ 00 -12 ~ 18 Image: Constraint of the shold: -10 ~ 00 -10 ~ 00 Image: Constraint of the shold: -10 ~ 00 -10 ~ 00	RTS/CTS Threshold:	2347	(0~2347)				
DTIM: 2 (1~255) Image: Bable Signal Threshold 354 Station Signal Threshold: -76 BBm (-20 ~ -76) Disassociate Station Threshold: -105 Image: Bable Signal Threshold: -105 Image: Bable Signal Threshold: -105 Image: Bable Station Threshold: -105 Image: Bable Station Connection after Multiple Retries Station Retry Count: 6 Image: Bable Station Mode: Image: Bable Station Mo	Beacon Interval:	100	(40ms~1000ms)				
✓ Enable Signal Threshold Station Signal Threshold: -76 dBm (-20 ~ -76) Disassociate Station Threshold: -105 dbm (-20 ~ -105) ✓ Allow Station Connection after Multiple Retries Station Retry Count: 6 (1 ~ 100) Multicast Settings Transmission Mode: Multicast to Unicast ● Fixed Multicast Rate Multicast Rate(Mbps): ● 1 ● 2 ● 5.5 ● 11 ● 6 ● 9 ● 12 ● 18 ● 24 ● 36 ● 48 ● 54 OK Cancel	DTIM:	2	(1~255)				
Station Signal Threshold: .76 dBm (-20 ~ -76) Disassociate Station Threshold: .105 dbm (-20 ~ -105) Image: Allow Station Connection after Multiple Retries station Retry Count: 6 Station Retry Count: 6 (1 ~ 100) Multicast Settings Transmission Mode: Multicast to Unicast Image: Price Multicast Rate Multicast Rate(Mbps): Image: Price Multicast Rate Multicast Rate(Mbps): Image: Price Multicast Rate OK Cancel	👿 Enable Signal Threshold						
Disassociate Station Threshold: -105 Image: Disassociate Station Threshold: -105 Image: Disassociate Station Connection after Multiple Retries Station Retry Count: 6 (1 ~ 100) Multicast Settings Transmission Mode: Image: Disast to Unicast Image: Disast Council Coun	Station Signal Threshold:	-76	dBm (-20 ~ -76)				
✓ Allow Station Connection after Multiple Retries Station Retry Count: 6 (1 ~ 100) Multicast Settings Transmission Mode: Multicast to Unicast Multicast Rate(Mbps): 0 24 36 48 54	Disassociate Station Threshold:	-105	dbm (-20 ~ -105)				
Station Retry Count: 6 (1 ~ 100) Multicast Settings Transmission Mode: Image: Contrast to Unicast to Unicast to Unicast to Unicast to Unicast Rate Multicast Rate(Mbps): Image: Contrast to Unicast Rate Image: Contrast to Unicast Rate Multicast Rate(Mbps): Image: Contrast to Unicast Rate Image: Contrast to Unicast to Unicast Rate Multicast Rate(Mbps): Image: Contrast to Unicast Rate Image: Contrast to Unicast Rate Image: Contrast to Unicast Rate Image: Contrast to Unicast Rate Image: Contrast to Unicast Rate Image: Contrast to Unicast to Unicast to Unicast Rate Image: Contrast to Unicast to	Allow Station Connection after the state of the state	er Multiple Retries					
Multicast Settings Transmission Mode: Multicast to Unicast Multicast Rate(Mbps): 1 2 0 5.5 24 36 48 54 OK Cancel	Station Retry Count:	6	(1 ~ 100)				
Transmission Mode: Multicast to Unicast Fixed Multicast Rate Multicast Rate(Mbps): 1 2 5.5 11 6 9 12 18 24 36 48 54 0K Cancel	Multicast Settings						
Multicast Rate(Mbps):	Transmission Mode:	Multicast to Ur	nicast 💿 Fixe	d Multicast Rate			
© 24 © 36 © 48 © 54 OK Cancel	Multicast Rate(Mbps):	1	5.5) 11 🔘 6	9	12	18
OK Cancel		24	6 🔘 48 🔘	54			
OK Cancel							-
						ок	Cancel

♦ Station Signal Threshold

Set the minimum client signal strength. A wireless client is allowed to connect to the AP only when its signal strength is stronger than the specified threshold.

The parameter -20 dBm is the strongest signal you can require and -76 dBm is the weakest.

♦ Disassociate Station Threshold

Set the minimum kick-off signal strength. When a wireless client's signal strength is lower than the specified threshold, the NXC disconnects the wireless client from the AP.

The parameter -20 dBm is the strongest signal you can require and -90 dBm is the weakest.

♦ Allow Station Connection after Multiple Retries

Select this option to allow a wireless client to try to associate with the AP again after it is disconnected due to weak signal strength.

♦ Notice

This feature detects the wireless signal from the AP. It means the strength calculation is based on the signal sent from the client and received by the AP. Since the AP is more sensitive than the wireless client, it can usually hear from a further distance than the client.

Dual-optimized Antenna Switch

Dual-optimized Antenna Switch Introduction

What is Dual-optimized Antenna Switch?

Today, most access points in the market are designed with single static radiation pattern, typically for ceiling-mount. When an AP with ceiling-mount pattern is installed in a wall-mount scenario, its signal coverage does not fit the wall-mount deployment. Adapting an AP with external antenna may be an alternative option. However, external antenna installation requires know-hows for antenna selection, and it would seem awkward for interior decoration.

The WAC6103D-I is an 802.11ac AP designed for dual-way installation of wall and ceiling-mount. Its dual-optimized antenna allows pattern optimization to adapt to both the wall and ceiling-mount installations. The installation technician can instantly change the antenna pattern via the physical antenna switch without rebooting the device. If needed, administrators can perform granular signal optimization per floor plan via software configuration remotely. With this flexibility, the WAC6103D-I easily fits wall-mount or ceiling-mount deployment without the hassles of antenna selection and signal coverage adjustment.

This Technology helps:

The dual-optimized antenna allows radiation pattern to be changed manually by adapting to versatile installations, thus delivering benefits such as:

- ♦ Coverage Optimization
- ♦ Dead Spots Elimination
- ♦ User Experience Improvement

Terminologies of Dual-optimized Antenna Switch

Physical Switch

Provide a dip switch at the rear side of the WAC6103D-I AP for pattern selection between wall-mount or ceiling-mount installation. By default, the setting is ceiling-mount.

Software Configuration

Software configuration replaces a physical switch to allow remote antenna pattern adjustment.

How Does It Work?

When you install a ceiling-mount designed AP on a wall, the strengthened signals become interference to the upper and lower floors.



The WAC6103D-I wall-mount pattern focuses the signals to the front end to eliminate interference to other floors.



Configuration

Controller/Managed AP

Web GUI Configuration Path: CONFIGURATION > Wireless > AP Management



Check the Current Status

Path: MONITOR > Wireless > AP information > Radio List

Z	YXEL NXC2500									
	MONITOR	AP List	Radio List							
		Radio List								
6.00	ZyMesh Station Info	t∰ № #	Loading	AP Description	Antenna	Frequency Band	Channel ID			
R,	Detected Device Log	1	-	AP-A0E4CB84B912	Wall	2.4GHz	6			
		2 [4	I Page 1 o	AP-A0E4CB84B912 f1 ▶ ▶ Show 50	vitems	5GHZ	36/40			

Standalone AP

Web GUI Configuration Path: MAINTENANCE > Antenna

Z	ZyXEL WAC6103D-I											
	MAINTENANCE	Antenna Switch										
े	 File Manager Diagnostics LEDs Antenna Reboot Shutdown 	Configuration Enable Software Control Radio1: Radio2:	WallWall	CeilingCeiling								

Check the Current Status

Web GUI Path: MONITOR > Wireless > AP information > Radio List

Z	ZyXEL WAC6103D-I												
	I	DASHBOAR	RD										
		🖶 WLAN	Interface Status Sum	mary		_	_	(© ¢ X			
		Status	MAC Address	Ra	dio	Band	OP Mode	Channel	Antenna	Station	_		
		@	A0:E4:CB:84:B9:13	1		2.4G	AP (MB	6	Wall	0			
R,		@	A0:E4:CB:84:B9:14	2		5G	AP (MB	36/40/4	Ceiling	0			
		Systen	n Status							4			
		System L	Jptime:		00:09	:33							
		Current [Date/Time:		2015-10-20 / 07:54:59 UTC+00:00								
		Current L	ogin User:		admin (unlimited / 00:30:00)								
		Boot Sta	tus:	System default configuration									
		Managen	nent Mode:		standalone								
		Power M	ode:		Full								

The WLAN LEDs indicate the real-time antenna pattern status



WLAN LED	Antenna Pattern	LED Color
	Ceiling-mount	Green
2.4GHZ LED	Wall-mount	Amber
	Ceiling-mount	Green
	Wall-mount	Amber

ZyXEL One Network Utility Supports Managed AP

ZyXEL One Network Introduction

What is ZyXEL One Network

The reality of today's networking business is that different product lines lack consistency and integration. In this industry, the equipment manufacturers often acquire new technologies for a shorter time-to-market. As a result, products under one brand might have totally different graphic or command line interfaces, or similar names for features that perform differently. As a networking brand that strives to deliver the best solutions to its customers, ZyXEL addresses this problem and aims to take the business of networking to a new height by introducing the ZyXEL One Network feature.

With the vision to make the world connect, ZyXEL presents comprehensive business networking solutions from switches to wireless, security appliances, and gateways. The robust, reliable networking equipments from ZyXEL, which is one of the few companies that possess the key technologies for all business networking product lines, enable us to fully integrate switches, wireless APs and gateways in an innovative way.



The easiest, most efficient network setup and management for businesses

ZyXEL One Network Utility helps:

- Discover deployed ZyXEL devices
- Change the default IPs and assign new ones
- Firmware upgrade
- Reboot devices
- Link to ZyXEL AP Configurator (ZAC) for advanced settings on a wireless AP

How Does It Work?

ZyXEL Discovery Protocol (ZDP) is used to realize the ZON Utility functions

- ZyXEL proprietary protocol
- When the user clicks the **Scan** button, the utility sends out multicast discovery packets to the broadcast domain.
- ZyXEL devices will reply via unicast to the ZON utility.
- Click the Scan button again to refresh the discovery of newly added devices.



What's New in V4.21

Before firmware v4.21, the ZON Utility can only discover and configure standalone APs. Since the release of firmware v4.21, the ZON Utility can discover not only standalone APs but also NXC controllers and managed APs.

la ZyXEL One Network Utilit	ty									-	-	-
	Z	YX	EL									
	۲۹۲ ۱۹۶۰ ۱۹۶۰	2		৻৽ৄ	((<u>o</u>)		⟨z₊⟩			ZAC	0
		Туре	V Model		Firmware Vers	MAC A	ddress	IP Addres	s	Syste	e <mark>m Name</mark>	Location
			NXC25	500	V4.21(AAIG.1)	10-7B-	EF-CF-E8-74	192.168.1	1.1	NXC2	2500	
\bigcirc			WACE	103D-I	V4.21(AAXH.1) A0-E4-	CB-84-B9-12	192.168.1	1.110			
		6	NWAS	123-NI	V4.21(AAHY.1) EC-43-	F6-FE-79-63	192.168.1	1.103	nwa5	123-ni	
	-											
ZyXEL One Network												

The above screen shows an example of the ZON Utility discovery: one NXC2500, one WAC6103D-I, and one NWA5123-NI. The WAC6103D-I is configured as a managed AP and the NWA5123-NI is configured as a standalone AP. With the new firmware v4.21, you can see that both AP modes can be discovered via the ZON Utility.

Notice:

- 1. Fuctions such as configuration through the device's web GUI, upgrading firmware, and changing the password are not permitted for managed APs.
- 2. ZAC is only available for standalone APs.

Portal Redirection on Managed AP Application

Portal Redirection on Managed AP Application Introduction

It is ideal to have captive portal application for controllers and APs located in different geographical locations or for hotspots without captive portal gateway deployment.



In FW release v4.20, captive portal redirect feature applies on the NXC controller only. From FW v4.21, captive portal redirect on Managed AP is introduced, which enhances network traffic efficiency without tunneling data traffic back to the NXC controller at the central site.

This provides more flexibility for web authentication configuration in both tunnel mode and local bridge mode.

How Does It Work?

There are two portal redirect modes on the new firmware 4.21: redirect on controller and redirect on AP. Redirect on AP is a new feature to process web authentication over distributed APs to reduce centralized traffic loading on the controller.



The portal redirect on AP traffic flow chart is as shown below.

Fundamental Configuration on GUI

1. In the **CONFIGURATION > Network > Captive Portal** screen, select **Enable Captive Portal**.

Z	YXEL NXC5500					
2	CONFIGURATION	Captive Portal	Redirect on Controller	Redirect on AP	Login Page	
	 ↔ Licensing ⇒ Wireless 	General Settings				
	Controller AP Management	Enable Capt	ive Portal			
000	+ MON Mode	Internal V	Veb Portal			
R.	Auto Healing	External	Web Portal			
	Network Captive Portal	Login l	JRL:			
	+ RTLS	Logout	: URL:			Optional
	Firewall	Welcon	ne URL:			Optional
	⊞ Object ⊞ System	Session	URL:			Optional
		Error U	RL:			Optional
		User-lo	gout URL:			Optional

2. Click the Redirect on AP tab and create an Authentication Policy Rule which is an SSID-based policy to filter the traffic from the AP.

ZYXEL NXC5500							
CONFIGURATION Licensing Vireless Controller AP Management MON Mode Auto Healing Network Captive Portal ABT S	Authentication Policy Group						
 Firewall Object System Log & Report 	Authentication I	Policy Rule dit TRemove @ Activate Name redirecto default a 1 of 1 > N Show	Inactivate SSID SNAP redire any v 50 v items	Profile			

3. Create an authentication policy group profile and include the rule entry created in Step 2.

Z	YXEL NXC5500						Wel
2	CONFIGURATION	Captive Portal	Redirec	t on Controller	Redirect on AP	Login Page	
	 Licensing Wireless Controller AP Management MON Mode Auto Healing Network Captive Portal RTLS Firewall Object System Log & Report 	Authentication I Authentication I Authenticatio I Authentication I Authentication I Authenticatio	Policy Gro	Comp Comp Comparison of the second	eference itcation Policy Grou ings e: redirectonAP Edit redirectonAP Edit Remove MI e ectonAP age 1 of 1 > > t' policy rule will be th	I Show 50 v i e last one for each s	al) tems Displaying 1 - 1 of 1
							OK Cancel

4. Select the policy for the AP group.

Noted: Portal redirect on the AP still needs the controller to be involved in the authentication flow. If the connection to the controller is lost, there is an option to skip authentication.

Z	YXEL NXC5500							-		Weit	
7	CONFIGURATION	Mgnt. AP List	AP Policy	A	AP Grou	p					
		Group setting									
46.	+ Controller	Default Group	:	2	Edit AP Group Setting						
1 00	+ MON Mode	Crown Summary			🕜 Ad	d 📝 Edit 🏌	🖥 Remove 🤇	Activate 🖗 Inac	tivate		
Ŀ.	Auto Healing	Group Summary			#	Status	Name	V	/ID	Member	
	 • Network • Captive Portal • 	🔘 Add 🏼 🖉 E	dit 🏢 Remov		1	@	vlan0	1		lan1,lan2,lan3	
	+ RTLS	# Group	Name 🔺		14 4	Page 1	of 1 🕨	▶ Show 50	✓ items	Display	
	+ Firewall □ Object	1 Unclas	sified	Load Balancing Setting							
	⊕ System	2 default									
	E Log & Report	I a a Pag	e 1 of 1		📄 En	able Load E	Balancing				
					Мо	de:		By Station Numb	er	*	
					Ma	x Station Nu	umber:	10	(1-	~127)	
						Disassocia	ate station wh	nen overloaded			
Portal Redirect on AP											
					Auth. I	Policy Group	o:	redirectonAP		~	
					🗸 Ski	p authentica	ation to provi	de contingency ac	cess while co	ontroller is unreachable.	

Application Scenario



Scenario Description:

The application scenario illustrated a common scenario in chain stores or café where provides hotspot service. In these venues, typically the NXC controller locates at the central site and APs locate in remote sites, and captive portal redirect is configured on the remote AP.

Misconfiguration Case Description:

If the controller is behind NAT and its authentication policy rule of redirect on the controller is configured without certain directions (for example, **any** to **any** force authentication), the authentication flow from the AP might require authentication again by the controller's authentication policy while authenticated traffic from the USG enters the controller. This kind of double authentication will cause portal redirect malfunction.

Suggested Solution:

- 1. Do not enable captive portal redirect on the NXC controller and on the Managed AP simultaneously.
- 2. Specify a secure source/destination traffic direction for the authentication policy over the controller, and avoid to specify a loose authentication policy such as "**any** to **any** force authentication" to prevent double authentication.

Configuration Example for Suggested Solution 2 :

 In the CONFIGURATION > Network > Captive Portal > Redirect on AP screen, click Add in the Authentication Policy Rule section to add a new rule. The SSID redirectonAP is used as an example. Any client that connects to this SSID will be required to perform authentication.

Z	YXEL NXC5500							Welcome adn	nin <u>Loqout</u>	?Help ℤ	About 🛉 Site Map	CObject Reference	🖵 Console 🛛
	CONFIGURATION	Captive Po	ortal Redirect on C	Controller	Redirect on AP	Login Page							
	NOVY MODE Auth-Healing Noving Noving												
~	+ Interface	Q Add Z Edit Z Edit Z Remove Diject Reference											
Routing # Name Description													
R.	Zone NAT	1	default										
	ALG	2 redirectonAP redirectonAP											
	IP/MAC Binding	4 4 Page 1 of 1 ≥ 1 Show 50 v Items Displ								Displayi	ng 1 - 2 of 2		
	Captive Portal RTLS												
	- Firewall	Authentic	auon Policy Rule										
	Object	© Add ≥ Edit 👕 Remove 💡 Activate 🖗 Inactivate											
	Oser/Group AP Profile	#	Status	Name	SSID	Profile	Source	Destination	Schedule		Authentication	Description	
	MON Profile	1	9	redirectonA	P redire	ectonAP	any	any	none		force	redirectonAF	,
	ZyMesh Profile	2		default	any		any	any	none		unnecessary		
	Address Service	14 4	Page 1 of 1	I Show 5	50 🔻 Items							Displayi	ng 1 - 2 of 2

2. Add this authentication policy rule to the Authentication Policy Group.

ZVXEL NXC5500			Welcome admin Le		
CONFIGURATION - MUCH MODUE - Auto Healing - Network - Interface - Routing - Zone - NAT - ALG - IPMAC Binding - Ceptive Portel - RTLS	Captive Portal Redirect on Controlle Authentication Policy Group Add 2 Edit 2 Remove 2 Obje # Name 1 default 2 redirectonAP 1 d Page 1 of 1 P	er Redirect on AP Login Page ct Reference s S C Edit Authenitcation Policy Group redirectonAP General Settings	Welcome admin		
 Captive Portal RTLS Firewall Object User/Group AP Profile MON Profile ZyMesh Profile ZyMesh Profile Address Service Schedule AAA Server Auth. Method Certificate System Host Name 	Authentication Policy Rule	General Settings Profile Name: redirectonAP Description: redirectonAP (Optional) Add ZEdit Remove at Move # Name 1 redirectonAP I redirectonAP I Page 1 of 1 ▶ I Show 50 v items Note: The "default" policy rule will be the last one for each group protein	Nisplaying 1 - 1 of 1		
 → USB Storage → Date/Time 			OK Cancel		

3. In the **AP Group** screen, select this authentication policy group in the **Portal Redirect on AP** field.

Note: Select the checkbox below this field to skip authentication when the controller is unreachable.

Z			Welcome admin Logout ? H
ø	CONFIGURATION	Mgnt. AP List AP Policy	AP Group
	 Licensing Wireless Controller Annancement MON Mode Auto Healing Network Interface Routing Zone NAT ALG IP/MAC Binding Captive Portal RTLS Firewall Object User/Group AP Profile AdVesh Profile Address Service Schedule AAA Server Auth. Method Certificate System Host Name USB Storage Date/Time Console Speed 	Group setting Default Group: Group Summary Add @ Edit @ Remov # Group Name ~ 1 Unclassified 2 defaut 4 @ Page 1 of 1	Edit AP Group Setting F Status Name VID Member Vian0 1 Ian1,Ian2,Ian3 Vian0 1 Ian1,Ian2,Ian3 I 4 Page 1 of 1 >>> Show 50 vitems Displaying 1 - 1 of 1 Load Balancing Setting Enable Load Balancing Mode: By Station Number v Max Station Number: 10 (1~127) Disassociate station when overloaded Portal Redirect on AP
			Auth. Policy Group: redirectonAP Skip authentication to provide contingency access while controller is unreachable. AP List Available AP-A0E4CB7FEB56(A0:E4:CB:7F:EB:56) AP-A0E4CB8016B2(A0:E4:CB:80:16:B2) CK Cancel Override Member AP setting

4. Remote wireless clients can be redirected to the portal login page with the local gateway IP (https://10.50.60.10) while connected to the remote AP.



5. What if the authentication policy rule is configured without certain directions, such as **any** to **any** force authentication?

XEL NXC5500							Welcome admin Logout	YHelp Z Abo		
ONFIGURATION	Captive Portal	Redirect on C	ontroller	Redirect on AP	Login Page					
∃ Licensing ⊕ Wireless	QR Code Conf	QR Code Configuration								
Network	Authentic	ation with QR code								
RTLS	Guest Acc	count:	Please s		× 1					
Firewall	Auther	enticator-assisted								
) Object	QR Por	rtal Address:	Please s		× 1					
Log & Report	Auther	nticator:	Please s		~					
	Self-s	serviced								
	QR Por	rtal Address:			× 1					
	Note M	lessage:								
	QR Co	de	Print O	ut QR Code						
	Authentication	Policy Rule								
	O Add	Edit 🍵 Remove 💡	Activate 🖗) Inactivate 📣 Move)					
	Add 2									
	Status	Priority Source		Destinatio	on	Schedule	Authentication	Descriptio		
	Status	Priority Source 1 any		Destinatio	on	Schedule	Authentication force	Descriptio		

6. The remote wireless clients can't be redirected to the portal login page successfully while connected to the remote AP. The root cause is double web authentication, which causes portal redirection to occur recursively.



 Continuing with step 5, if the authentication policy rule is configured with a certain direction, for example, LAN_SUBNET to any force authentication, the remote wireless clients can be redirected to the portal login page successfully.

-				_				Welcome admin Logout	?Help	Z About
-	YAEL NACSSUU									
	CONFIGURATION	Captive Portal	Redirect on Cont	roller	Redirect on AP	Login Page				
	 H Licensing → Wireless 	QR Code Config	guration							
<u></u>	Network Captive Portal	Authentica	tion with QR code							
6.0	+ RTLS	Guest Acco	ount:			× 1				
R	+ Firewall	Auther	nticator-assisted							
	Object System	QR Port	al Address:	Please se		× 1				
		Authent	icator:			~				
		Self-se	erviced							
		QR Port	al Address:			× 1				
		Note Me	essage:							
		QR Coo	ie 🚺	Print Ou	t QR Code					
		Authoptication	Doliov Bulo							
		Autoentication	Policy Rule							
		💿 Add 📝 E	dd 📝 Edit 🍟 Remove 💡 Activate 🔞 Inactiv			rate 🙀 Move				
		Status F	riority Source		Destinatio	ı	Schedule	Authentication	De	escription
		<u></u> 1	LAN_SUE	BNET	any		none	force	re	directonAC
		C	efault any		any		none	unnecessary	n/	а
		🛛 🗐 🖉 🖓 Pag	e 1 of 1 🕨 🕅	Show 5	0 🔻 items					



Conclusion:

Portal redirection on the AP is a new feature for the 11ac generation. The legacy captive portal will be handling all tasks of the controller, which has to process either authentication or data traffic from distributed traffic. 11ac is a new WiFi technology with more throughput than the 11n. To transfer to the 11ac will be a big challenge for the structure of the controller. How to offload the traffic stress on the controller is currently an important issue. ZyXEL's new technology, the Portal Redirect feature on the AP is considered an innovation to separate the authentication traffic and data flow on local site APs. As long as clients pass the captive portal authentication, all the traffic can be unloaded locally to save the remote bandwidth. Thus, the controller's traffic loading is reduced.