Wi-Fi 6 AX3000 Dual Band PCI Express Adapter with Bluetooth 5.0 Support

Wi-Fi 6 двухдиапазонный PCI Express адаптер AX3000 с поддержкой Bluetooth 5.0

Wi-Fi 6 дводіапазонний PCI Express адаптер AX3000 з підтримкою Bluetooth 5.0

Bluetooth 5.0 қолдаумен Wi-Fi 6 екі диапазонды PCI Express адаптері AX3000

DWA-X582

Quick Installation Guide
Краткое руководство по установке
Короткий посібник зі встановлення
Орнату бойынша қысқаша нұсқаулық

ENGLISH

PACKAGE CONTENTS

- **DWA-X582 Wireless PCI Express Adapter**
- **Two 2.5 GHz/5 GHz Antennas**
- **Quick Installation Guide**

If any of these items are missing from your packaging, please contact your reseller.

INSTALLATION

1. Download the required driver on the DWA-X582 description page from the www.dlink.com website.
2. Turn off your PC and disconnect the power cable. Open the housing of your PC to get access to the motherboard.
3. Insert the DWA-X582 adapter carefully and firmly into any available PCI Express slot. Secure the adapter with a screw.
4. Attach the housing of your PC and reconnect the power cable. Attach both antennas to the DWA-X582 adapter and power on your PC.
5. If the "Found New Hardware Wizard" dialog box appears, press "Cancel".
6. Open a folder with the required driver and run the "setup.exe" file to install the driver.

SETUP AND CONFIGURATION PROBLEMS

1. **What should I do, if I've forgotten my wireless encryption key?**
   The wireless encryption key is configured at the Wireless Access Point or Router. If you are unable to obtain your encryption key, the only solution would be to reconfigure your Access Point/Router to use a new encryption key. Please contact your Wireless Access Point/Router manufacturer.

2. **Why can't I get a wireless connection?**
   - Check that your DWA-X582 is plugged in properly to the PCIe slot or try to plug the DWA-X582 into another PCIe slot if it is available
   - The LED on the DWA-X582 should be lit, otherwise there could be a physical fault on the PCIe slot or the driver is not installed properly.
   - Ensure that the wireless settings on the DWA-X582 match the settings on your Access Point/Router. Please check and confirm your settings for **Wireless Network Name (SSID)** **Wireless Encryption Key** **Wireless Security Method (e.g. WEP, WPA3)** to check whether a wireless connection has been made, in the Windows System Tray (bottom right).
   - Check that your Internet is working fine on existing computers.
   - Ensure that you have followed and completed the software installation process, otherwise, please reinstall the software. The LED on the DWA-X582 should come on after software installation.